



APPLICATION INSTRUCTIONS

It's not just a pattern... It's a way of life.



1 Materials & Surface Preparation

- Lint Free Cloth
- Painter's Tape
- Scissors or Knife
- Squeegee

Make sure the surface is clean and smooth. The graphic will not adhere to stucco or brick like surfaces.



2 Prepare Graphic

The graphics have a transfer tape (looks and feels like white masking tape) on one side and backing paper (white and shiny) on the other. Graphics can be cut apart, if needed, and arranged in any manner you desire. Taping them lightly in place first will help you plan your layout. When your placement has been determined, securely tape the graphic in place with a low tack painter's tape. Run a strip of tape vertically down the center of the graphic and on the left edge of the graphic.



3 Application

Flip the right half of the graphic back toward the left half of the graphic until it bends back to the center hinge. Peel the backing paper away from the graphic, by pulling it back over itself at about a 180° angle. Cut that half of the backing paper from the graphic close to the center hinge. The graphic should remain on the transfer tape.



4 Burnishing

Flip the right side of the graphic back down toward the surface and tauntly hold it away from the surface a couple inches. Using a squeegee, carefully press the graphic onto the surface in a slow sweeping motion, working from the center outward. This will force any air bubbles out from underneath the graphic. Pull the left side of the graphic back toward the right and remove the remaining backing paper. Flip the left side back toward the surface and squeegee the graphic. Burnish again, apply more pressure over the entire area.



5 Transfer Tape Removal

Carefully peel the transfer tape back at about a 180° angle. This will leave the graphic on your surface. Enjoy your new look.